

Start saving today!

Save energy and money in just a few steps

Congratulations on completing your WarmWise Home Savings Evaluation. After completing the evaluation you should have reviewed your personalized recommendations explaining steps you can take to save more on your natural gas bills. Also, for completing the evaluation you are receiving this free energy efficiency water heating kit to help get the savings started.

Install items in your energy efficiency water heating kit

Please see the reverse side for installation instructions. We have thoughtfully selected items that work to save energy without sacrificing your comfort.

You could save even more...

Be sure to visit ColumbiaGasVA.com/WarmWise for more information.

This is just the first step in saving on your natural gas bills with Columbia Gas's WarmWise Program. Check out our high efficiency natural gas furnace/boiler, dryer, water heater, fireplace, smart thermostat, windows, doors and skylights rebates at

ColumbiaGasVA.com/Rebates.

This energy efficiency water heating kit was packaged with care and pride in the USA by employees of AM Conservation. Please recycle all packaging materials.

Columbia Gas of Virginia
WarmWise@ColumbiaGasVA.com

Visit ColumbiaGasVA.com/WarmWise for more information.

Columbia Gas®
A NiSource Company



Bathroom Aerator



Kitchen Aerator



Shower Head

High-Efficiency Faucet Aerators

To Install:

Carefully remove any existing aerator by twisting the cap to the left. If the cap is too tight, use pliers or a small pipe wrench to remove by hand.

Place the rubber washer inside the end of the new aerator and hand tighten the aerator onto the faucet.

Check the faucet by turning on the cold water. If you detect a leak, tighten the aerator either by hand or gently using pliers. Do not over tighten, and be careful not to scratch if using pliers.

High-Efficiency Shower Head

To Install:

Carefully remove the existing shower head by twisting it to the left, using a wrench or pliers if needed. With the old head removed, clean the threads of the exposed pipe.

Use the enclosed Teflon tape to wrap around the cleaned threads four times. Hand tighten the new shower head to the pipe.

Using the wrench or pliers, grip the base of the shower head and carefully tighten it enough so that the water does not leak.

Instructions courtesy of ehow.com.

* Based on information provided by the manufacturer.

Images are for reference only.

To learn more ways to save,
visit ColumbiaGasVA.com/WarmWise

Columbia Gas
A NiSource Company