

Start saving today!

Save energy and money in just a few steps

Congratulations on completing your WarmWise Home Savings Evaluation. After completing the evaluation you should have reviewed your personalized recommendations explaining steps you can take to save more on your natural gas bills. Also, for completing the evaluation you are receiving this free energy efficiency gas heating kit to help get the savings started.

Install items in your energy efficiency gas heating kit

Please see the reverse side for installation instructions. We have thoughtfully selected items that work to save energy without sacrificing your comfort.

You could save even more...

Be sure to visit ColumbiaGasVA.com/WarmWise for more information.

This is just the first step in saving on your natural gas bills with Columbia Gas's WarmWise Program. Check out our high efficiency natural gas furnace/boiler, dryer, water heater, fireplace, smart thermostat, windows, doors and skylights rebates at ColumbiaGasVA.com/Rebates.

This energy efficiency gas heating kit was packaged with care and pride in the USA by employees of AM Conservation. Please recycle all packaging materials.

Columbia Gas of Virginia
WarmWise@ColumbiaGasVA.com

Visit ColumbiaGasVA.com/WarmWise
for more information.


A NiSource Company



Switch and Outlet Insulation Gaskets



Silicone Caulk



Foam Sealant

Switch and Outlet Insulation Gaskets

How to use:

1. Shut off circuit breaker at fuse box.
2. Remove switch or outlet plate.
3. Pop out cut-outs from foam gasket.
4. Put gasket in place and re-attach plate.
5. Turn power back on.

Silicone Caulk

How to use:

1. Carefully cut nozzle at a 45 degree angle. Cured bead should be between 1/8" to 1/2". Use a foam backer rod (not included) for joints that exceed 1/2" in depth.
2. Smooth bead with a moistened cloth.
3. Clean up uncured material and tools with soap and water.
4. Allow 4 to 6 hours before painting.
5. Tools can be cleaned prior to curing with soap and water.

COVERAGE: 55 linear feet for 3/16" bead. Not intended for areas that will be submerged in water. Keep container from freezing. Not for food contact surfaces. Keep out of reach of children.

Foam Sealant

How to use:

1. Wear protective glasses or goggles, nitrile gloves and clothing that protects against dermal exposure. Use only in a well ventilated area.
2. Shake well. Screw nozzle adapter onto valve stem, being careful not to activate valve.
3. With valve end of can down, slowly press trigger to dispense foam. Test on experimental surface.
4. Fill cavity only 1/3 full with foam to allow for expansion. For cavities greater than 3 in. (75 mm) diameter, moisten substrate before applying.
5. Dries tack-free in approximately 5 minutes, cuttable within 1 hour, cures in 12-24 hours. Do not disturb uncured foam.
6. Uncured foam may be removed with HandiFoam Multipurpose Cleaner. Cured foam must be removed mechanically.
7. Cured foam can be trimmed or sanded. Cured foam exposed to sunlight must be covered with paint or stain.
8. Store upright in a dry area. Leave nozzle on can. To reuse, cut 1 in (3 mm) off nozzle tip.
9. Use remainder of can within 30 days.

This product is extremely flammable during dispensing. Read cautions carefully.

Optimum temperature for use is between 65-80 degrees Fahrenheit. Clean dust, grease and oil off surfaces to be foamed. Cover surrounding surfaces.

Images are for reference only.